## PARTS CATALOG

FOR

# Ongn ELECTRIC GENERATING PLANTS

WA SERIES


SPEC. A THROUGH E



## INSTRUCTIONS FOR ORDERING REPAIR PARTS


#### ONAN PARTS

All parts in this list are Onan parts. For Onan parts or service, contact the dealer from whom you purchased this equipment or your nearest authorized service station. To avoid errors or delay in filling your order, please refer to the Onan nameplate located on the upper right side of the flywheel housing and give the complete:



#### WAUKESHA PARTS

All Waukesha parts must be ordered from the Waukesha Motor Company of Waukesha, Wisconsin, or their nearest authorized distributor. Refer to the Waukesha Engine flywheel housing. When ordering parts, always supply Waukesha with the following nameplate information:





27

### PARTS CATALOG

This catalog applies to the standard WA plants as listed below. Powered by a Waukesha F-817-GE engine (see Waukesha Manual). Engine parts modified or added by Onan will be in this list and have Onan part numbers. These supersede similar parts listed in the Waukesha manual. Onan parts are arranged in groups of related items and are identified by a reference. All parts illustrations are typical. Using the Model and Spec. No. from the Onan plant nameplate, select parts from this catalog that apply to your plant. Unless otherwise mentioned, parts are interchangeable. Right and left plant sides are determined by facing the front end of the engine.

#### PLANT DATA TABLE

MODEL	. & SPEC NO. *	ELECTRICAL DATA						
	. 4 5, 20 110.	WATTS**	VOLTS	CYCLES	PHASE	WIRE		
HOUSED	UNHOUSED							
100WA-53R/	100WA-53R8/	100,000	120/240	50	t	] 3		
100WA-54R/	100WA-54R8/	100,000	120/208	50	. 3	4		
100WA-54XR/	100WA-54XR8/	100,000	277/480	50	3	1 4		
100WA-55DR/	100WA-55DR8/	100,000	120/240	50	3	4		
100WA-57R/	100WA-57R8/	100,000	220/380	50	3	4		
100WA-59XR/	100WA-59XR8/	100,000	347/600	50	3	4		
II5WA-3R/	115WA-3R8/	115,000	120/240	60	t	1 3		
115WA-4R/	115WA-4R8/	115,000	120/208	60	· a	4		
I I5WA-4XR/	115WA-4XR8/	115,000	277/480	60	3			
IISWA-5DR/	115WA-5DR8/	115,000	120/240	60	3	4		
115WA-6R/	115WA-6R8/	115,000	480	60	3	;		
H5WA-9XR/	115WA-9XR8/	115.000	347/600	60	3	] 4		

<sup>\* -</sup> The Specification Letter advances (A to B, B to C, etc.) with manufacturing changes.

#### REPLACEMENT ENGINE

Refer to factory giving complete Model, Spec, and Serial Number from plant (Onan) nameplate.


#### General Description:

Includes - Complete Cylinder Block, Carburetor, Air Cleaner, Oil Filter, Starter Motor, Distributor, High Tension Leads, Coil, Spark Plugs, Governor Fan Blades and Belt, Flywheel and Flywheel Housing, Water Pump, Radiator, Fan Guard, Oil Pan, Vibration Damper, Exhaust Manifold, Intake Manifold, Alternator Adjusting Bracket, and Lifting Eyes.

Excludes - Alternator, Voltage Regulator, Oil Pressure and Water Temperature Gauge and Ammeter.




<sup>\*\* -</sup> Maximum Standby rating, continuous rating is also shown on Onan nameplate.



REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
	.03.00.00		Base, Mounting	12	309A17B	1	Switch, Water Temperature Cut-Off - Non Adjustable
_	403C547 403C604	1	Unhoused Plants Housed Plants	12A	505-117	1	Bushing, Face - Water Temperature Switch
3	193A108 193A104		Sender, Oil Pressure Gauge Sender, Water Temperature Gauge	13	505-19	ı	Bushing, Pipe Reducer (1/2 x 3/8") - Water
4	CABLE, 416A443	BATTERY	Negative	14	133B150	1	Temperature Gauge Sender Baffle, Heat - Temperature
5	416A442 416A446		Positive Cable, Battery Jumper	15	191-543	ţ	Cut-off Switch Alternator, Battery Charging
6	314-156 314P6	6	Suppressor, Spark Plug Suppressor, Coil	16	232A1813	I	(with fan) - Begin Spec D Spacer, Alternator Mounting -
8	312A15	3	Condenser - 0.1 Mfd (1)	17	191-542	1	Begin Spec D Regulator, Charging - Begin
			Charge Generator, (1) Charge Regulator (1) Ignition Coil	·		•	Spec D
9 10	309 B 10 505-98	1	Switch, Oil Pressure Nipple, Close (1/8 × 3/4")Oil	18	191-544	'	Harness, Wiring - Alternator to Regulator - Begin Spec D
			Pressure Tee to Crankcase Tee, Pipe (1/8") Oil Pressure	19	191-545	1	Resistor, Alternator (75-Ohm)- Begin Spec D
11	505-5 <b>9</b>	t	Switch & Sender Mounting	20	191-623	1	Pulley, Alternator - Begin Spec D






REF.	PART NO.	QTY. USED	PART DESCRIPTION
I	STUD, AD	JUSTING	
	150A146	1	Gasoline Plants
	150A213	ı	Gas-Gasoline & LPG-Gasoline Plants
2	145A119	ŀ	Spring, Throttle
3	145A118	I	Link, Throttle Spring
4	150A302	1	Spacer, Linkage - Ball Joint to Throttle Spring Link
5	BRACKET	. SOLENO	ID & CHOKE MOUNTING
	145A217	į.	Gasoline Plants
	145A242	ı	Gas-Gasoline & LPG-Gasoline Plants
6	150A638	1	Joint, Ball - Solenoid Link to Throttle Spring Link
7	LINK, SOL	ENOID TO	BALL JOINT
	145A124	į.	Gasoline Plants
	145A241	1	Gas-Gasoline & LPG-Gasoline Plants
8	307 B259	1	Solenoid & Lead Assembly
9	336A179	ł	Lead, Solenoid to Connector
FO.	191A214	1	Connector, Lead Terminal

RE NO			PART DESCRIPTION
11	309A131	1	Bracket, Micro Switch Mtg Begin Spec C
12	309A155	1	'Switch, Micro - Begin Spec C
13	309P133	ŧ	Actuator, Micro Switch - Begin Spec C
14	309A132	1	Cam, Micro Switch - Begin Spec C
15	516-86	1	Pin, Roll (1/8 x 3/4") - Cam - Begin Spec C
16	145A221	1	Bracket, Throttle Spring
17	153P213	I	Choke, Auto. (Sisson) - Gas- Gasoline & LPG-Gasoline Plants
18 153A4	==: ::	Cover Assy, Choke - Gas- Gasoline & LPG-Gasoline Plants	
19	153A285	I	Arm, Choke Lock - Gas- Gasoline & LPG-Gasoline Plants
20	153A207	I	Adapter, Choke - Gas-Gasoline, LPG-Gasoline & Gas Only Plants





REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
21	153A286	1	Shaft, Choke - Gas-Gasoline, LPG-Gasoline & Gas Only Plants	26	5 18-47	l	Clip, Rod End (Adapter End) - Gas-Gasoline & LPG-Gasoline Plants
22	COUNTER	WEIGHT,	CHOKE SHAFT	27	153A283	1	Arm, Choke Over-Ride - Gas-
	148 A3 17	ŧ	Gas-Gasoline & LPG-Gasoline Plants				Gasoline & LPG-Gasoline Plants
	148A430	* F	Gas Only Plants	28	518-5	1	Clip, Rod End (Choke End) -
23	153 A206	ŀ	Plate, Choke - Gas-Gasoline, LPG-Gasoline, & Gas Only				Gas-Gasoline & LPG-Gasoline Plants
			Plants	29	508-7	2	Washer, Choke Shaft Seal - Gas-
24	153A282	ŧ	Arm, Choke - Gas-Gasoline & LPG-Gasoline Plants				Gasoline & LPG-Gasoline Plants
25	153A284	1	Rod, Choke - Gas-Gasoline & LPG-Gasoline Plants		•		



REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	
<del></del>	159B668	1	Tank, Reservoir	7	505-57	2	Plug, Pipe - Square Head
2	159A523	1	Bracket, Tank Mounting				(4/8)
3	159A121	ı	Band, Tank	8	50 I A85	2	Line, Fuel - Flexible - (1)
4	504-59	1	Valve, Tank Shut-Off				Pump to Reservoir Tank.
5	502-183	ı	Elbow, Compression Male - Brass				<ol> <li>Reservoir Tank to Carburetor</li> </ol>
6	BUSHING.	PIPE REI	DUCER	9	159A705	1	Bushing, Reducer - Restricted
	505-19	1	l/2" to 3/8"	10	501-9	1	Line, Fuel Return - Flexible
	505-17	2	3/8" to 1/4"	11	502-2	1	Elbow, Inverted Male - Return Line to Tank







#### GENERATOR GROUP (Alternator Portion)

NOTE: Output Terminal Box, Cover & Internal Parts listed in the AC Output Control Group (Mounts in side of generator).

REF.	PART NO.	GTY. USED	PART DESCRIPTION
1	•	1	Rotor Assy., Wound, Includes Bearing, Blower & Drive Assy.
2	BEARING		
	510P63	ı	Prior to Spec E
	510P88	ŀ	Begin Spec E
3	205C61	I	Blower
4	*	I	Stator Assembly, Wound
5	212C248	1	Rig Assy., Brush, Includes Brushes & Springs
6	21281105	4	Spring, Brush
7	214A56	4	8ru sh
8	211D153	I	Bell, End, Alternator to Exciter - NOTE: Prior to Spec E also order #232A1807 Holder, #232A1808 Spring, #510P88 Bearing, #526A17 Spacer & #812-192 Screw.
9	234D69	1	Baffle, Air
10	HOLDER, I	BEARING	
	232A1186	1	Prior to Spec E
٠	232A1807	1	Begin Spec E

REF.	PART NO.	QT USI	TY. PART ED DESCRIPTION
11	SPRING,	BEARING	HOLDER
	232A1187	' 1	Prior to Spec E
	232A1808	i i	Begin Spec E
12	232D1396	i - 1	Support, Generator Mounting
13	805-35	4	Bolt, Place, Gen. Mounting
14	150A717	ı	Switch Assy., Overspeed
15	150A713	t	Bracket, Overspeed Switch Includes Contact Point
16	234D70	i	Band, Gen., Frt. Port. (Narrow)
17	•	1	Band, Gen., Rear Port. Upper Half (Wide)
18	•	1	Band, Gen., Rear Port. Lower Half (Wide)
19	336A1213	1	Lead Assy., Overspeed Switch
20	234A107	1	Bracket, Conduit Connector
21	204AB3	1	Ring, Collector


\* - Order by description, giving complete Model, Spec and Serial Number (Onan Nameplate).



#### **GENERATOR GROUP (Exciter Portion)**


REF.	PART NO.	QTY. USED	PART DESCRIPTION
	209-24	1	Magneciter Assembly, Complete- Spec A Only
	209-25	1	Magneciter Assembly, Complete Begin Spec B
1	COVER, EX	CITER	
	234D73	1	Spec A Only
	234D116	1	Begin Spec B
2	232A1376	3	Bracket, Fastening, Cover to Alternator End Bell
3	234D74	1	Panel Only, Exciter
4		ASSEME	BLY, POWER - COMPLETE
•	305B206	ı	Spec A Only (Includes (4) #305-205 Rectifier Plus Wire & Hardware)
	305B228	I	Begin Spec B (Includes (2) #305P233 & (2) #305P234
			Rectifier Plus Wire&Hdwe.)
	RECTIFIER	ONLY,	POWER (Field)
5	305-205	4	Spec A Only (Included in
			Rectifier Assy, #305B206)
5	305P233	2	Lower Two, Neg. (Included in
			Rectifier Assy, #305B228)- Begin Spec B
6	305P234	2	Upper Two, Positive (Included
			in Rectifier Assy, #305B228) - Begin Spec B
	REACTOR,	VOLTAC	GE CONTROL
7	315B53	ļ	Spec A Only (Includes #304-443 Resistor & (4) #305B203
			Rectifier)
8	315A78	1	Begin Spec B
9		VOLTAC	SE CONTROL REACTOR
	304-443	i	Spec A Only (included in Reactor Assembly #315B53)
	304P476	I	Begin Spec B (Included in Rectifier & Resistor Assy. #305B227)
	CTDID MAD	V = 0 \	VOLTAGE CONTROL REACTOR
		K = N	VOLTAGE CONTROL REACTOR
10	Spec A Only 332A644	1	Marked + . C. –
11	332A645	i	Marked I, 2, 3, 4
11			
	REACTOR		NG - VOLTAGE CONTROL
12	232B1404	1	Spec A Only
13	234B115	1	Begin Spec B
14	234B75	2	Bracket, Gate Reactor Mtg.
15	520A 190	1	Stud, Resistor Mtg.
16	304A15	2	Washer, Resistor Centering
17	304-442	ł	Resistor, Fixed, Mounts to Gate Reactor Bracket
18	315A51	2	Reactor, Gate
19	232A1389	2	Retainer, Gate Reactor
20	232A1403	2	Stud, Gate Reactor Mounting
21	232B1388	2	Gasket, Gate Reactor Mtg.
22	232B1387	2	Gasket, Gate Reactor to Retainer
23	232A1548	2	Gasket, Control Reactor

Coil Mtg.



REF.	PART NO.	QTY. USED	PART DESCRIPTION
	BLOCK, T	ERMINAL	
24	232A503	ı	Spec A Only (B-Place)
25	232A532	1	Begin Spec B (5-Place)
	STRIP, TE	ERMINAL	BLOCK MARKER
26	332A643	ì	Spec A Only (8-Place)
27	332A693	l l	Begin Spec B (5-Place)
	RECTIFIE	R. VOLTA	GE CONTROL REACTOR
28	305-203	4	Spec A Only (Included in #315B53)
29	305P218	4	Begin Spec B (Included In #305B227)
30	305B227	ŀ	Resistor Assy., Rectifier (Includes #304P476 Resistor & (4) Rectifier #305P218) - Begin Spec C





NO.	NO.	USED	DESCRIPTION	NO.	NO.	USED	DESCRIPTIONS	
1		1	Panel Only, Upper Control	11	VOLTMETER	R, AC (CI	heck Scale & Select According	g
2	BOX ONLY	, CONTR	OL	Į.	to Rating)			
	301D1537	1	Prior to Spec C		302P421	ŧ	Scale 0-300	
	30 I D2 I I 5	1	Begin Spec C	1	302P422	ŧ	Scale 0-600	
3	30 IC1830	~ <b>}</b>	Bracket, Control Box Mtg.		302P423	1	Scale 0-750	
5	402-78	4	Mount, Rubber, Control Box Mounting	12	AMMETER, A	AC (Chec OTE: I-f	k Scale & Select According Phase Use 2.	
6	337A44	1	Strap, Ground		302P411	1	Scale 0-200	****
9	30 IA 19 14	ı	Bracket, Panel Stop -		302P412	1	Scale 0-250	` ````````````````````````````````````
			Begin Spec C	1	302P414	i	Scale 0-500	1 1
10	508-63	ŧ	Grammet (2-3/4" Hole) -	i	302P415	I	Scale 0-750	
Tims	Power		Begin Spec D	•			Redistribution or publication of t	this document




NO.	PART NO.	QTY.	PART DESCRIPTION
I 3	METER, RU	NNING T	IME
-	302-212	1	60 Cycle Plants - Prior to
	JV2-212	•	Spec C (To replace #302-387
			Meter req. Resistor, also order
			#304A125 Resistor for 480 V
			Plants & #304A99 Resistor for
			120/240 V. 3 phase plants)
	202 102	1	50 Cycle Plants - Prior to Spec C
	302-102 302P465	i	120/240 Volt. 1, Phase, 60 Cycle,
	302F400	•	120-208, 120/240, 600, and
			347/600 Volt, 3 Phase, 60 Cycle
			Plants - Begin Spec C
	202D466	1	220/380 Volt, 3 Phase, 60 Cycle
	302P466	ţ	Plants - Begin Spec C
	202247	1	277/480 Volt, 3 Phase, 60 Cycle
	302P467	•	Plants - Begin Spec C
			220/380 Volt, 3 Phase, 50 Cycle
	302P469	l	Plants - Begin Spec C
		1	120/208 Volt, 120/240 Volt, 600
	302P468	1	Volt, and 347/600 Volt,
			3 Phase, 50 Cycle Plants -
			Begin Spec C
			277/480 Volt, 3 Phase, 50 Cycle
	302P470	ı	Plants - Begin Spec C
			Switch, Volt & Current Selector
14	308-22	i	(3 Phase Only)
	_		Upp FAIT (Chack Transformer
15	TRANSFO	RMER.	URRENT (Check Transformer
			According to Rating) Nameplate Ratio 200/5 (Use
	302B106	3	with 0-200 AC Ammeter)
		_	Nameplate Ratio 250/5 (Use
	302B209	2	with 0-250 AC Ammeter)
	302B372	3	Nameplate Ratio 500/5 (Use
			with 0-500 AC Ammeter) Nameplate Ratio 750/5 (Use
	302B3B5	3	with 0-750 AC Ammeter)
			with 0-750 AC Ammerer
			NOTE: I-phase use 2.
16		R, CIRCU	IT Disease Blooms 20 Amb
	320B18		I Phase Plants - 20 Amp.
	320 B2		3 Phase Plants - 15 Amp.
17		FREQUE	NCT (ACuela Plants
	302-213	ł	60 Cycle Plants
	302-234	.	50 Cycle Plants
18			UENCY METER For 480 V & 277/480 V, 3 Phase
	304A305	ı	For 480 V & 2777 400 V, 51 11050
			Plants (45,000-Ohm, 10-Watt) For 120/240 V, 3 Phase Plants
	304A125		FOF 120/ 240 V, 3 Fit23e 1 Tails
			Spec A Only and 220/380 Volt 3 Phase Plants - Begin Spec C
			(15,000-Ohm, 25-Watt)
	304A402	I	For 600 Volt, 3 Phase Plants -
			Begin Spec C (60,000-Ohm,
			10-Watt)
19	332A604	i	Block, Terminal (5 Place) -
.,			Begin Spec B
20	332A690	1	Strip, Marker (5 Place) -
			Begin Spec B
21	303-111	1	Rheo stat, Voltage Regulator -
-	•		Begin Spec B
22	303-32	1	Knob, Rheostat - Begin Spec B
23	-	1	Resistor, Voltage Regulator
دے	. 22		825-Ohm, 75-Watt) - Begin

Spec B

REF.	NO.	QTY.	PART DESCRIPTION						
24	•	t	Box, Output Terminal (Side of Generator)						
25	*	` <b>j</b>	Cover, Output Terminal Box						
26	302-157	1	Multiplier, Meter (Used only with Early 0-500 Scale Voltmeter)						
27	RESISTOR, 304A99	RUNNIN	G TIME METER 5,000-Ohm, 10-Watt (For #302-212 Meter on 120/240 V, 3 Phase,						
	304A125	ı	60 Cycle Plants - Spec A Only) 15,000-Ohm, 25-Watt (For #302-212 Meter on 480 V Plants)						
	304A444	l	- Prior to Spec C 2, 500-Ohm, 10-Watt (For #302-387 Meter on early 120/240 V, 3 Phase, 60 Cycle Plants -						
	304A445	l	Spec A Only) 6, 500-Ohm, 25-Watt (For #302-387 Meter on early 480 V, 3 Phase, 60 Cycle Plants -						
	304A536	1	Spec A Only) 9,000-Ohm, 50 Watt (Use on 600 Volt, 3-Phase, 60 Cycle Plants) - Begin Spec C (For 302P465 Meter)						
28	302B448	As Re							
29	332A503	As Ne	Block, Terminal (8-Place)						
30	332A601	i	Strip, Marker (15 through 22)						
50	BRACKE	r. CURR	ENT TRANSFORMER						
31	232B   39	1	Upper (large)						
32	232C 1390	1	Lower (small)						
33	*	ŧ	Panel, Current Transformer Mtg. (Bottom) - Spec A Only						
34	•	ŀ	Panel, Current Transformer Retaining (Top) Spec A Only						
			FERMINAL (As Req.) - Spec A Only						
35			7/8-14 x 6-1/2"(1 Phase use 3)						
	232A1420		5/8-18 × 6"						
36	232A1400	niteit	TERMINAL - STUD TO GRD.						
30	(As Req.)	- Spec A	A Only						
	337A58	JPCC .	3-3/8" x 1-1/2"						
	337.A57	1	3-1/4" x 1"						
37	STRAP.	DUTPUT	TERMINAL - GRD STUD TO MACH.						
	SCREW (	As Reg.)	- Spec A Only						
	232A1416		2-3/4" x 1-1/2"						
	232A1397		2-1/4"x 1"						
38	STRAP,	DUTPUT	TERMINAL - UNGRD. STUD TO						
			s Req.) - Spec A Only						
	232A1415		4-1/4" x 1-1/2"(1 Phase use 2) 3-3/8" x 1"						
20	232A1398	NEOPP	ENE INSULATING - TRANSFORMER						
39	MOUNTI	JG (As R	eq.) - Spec A Only						
	508 A8 I	6	2-1/2" I.D. x 4-1/2" O.D.						
	J00.10 /	_	(I Phase use 4)						
	508 A 7 9	6	1-3/4" 1.D. × 3" O.D.						
40	WASHER	FIBER	- TRANSFORMER MOUNTING						
	(As Req.	) - Spec	A Only						
	508 A83	3	7/8″1.D. x 2-1/4″ O.D.						
	508 A82	3	(1 Phase use 2) 5/8″1.D. x 1-1/2″O.D.						
<ul> <li>Order by description, giving Model, Spec &amp; Serial</li> </ul>									
• -	Order by des Number (Ona	cription, n Namep	giving model, spec & sellar						





REF. NO.	PART NO.	QTY.	PART DESCRIPTION
1	PANEL ON	LY - LO	WER CONTROL
	301C1672	l l	Prior to Spec C
	30 I D2 I 24	ŀ	Begin Spec C
3	SWITCH, T	OGGLE	
	308 P2	I	Prior to Spec C (Run, Stop, Auto)
	308P138	<b>!</b>	Begin Spec C (Run, Stop, Remote)
4	308P2	ŀ	Switch, Panel Light - Begin Spec F
5	302A61	ŧ.	Ammeter, Charge (30-0-30)
6	193B106	1	Gauge, Water Temperature
7	193B107	T T	Gauge, Oil Pressure
8	332A607	ł	Block, Terminal (12-Place)
9	332A608	1	Strip, Marker (4 through 15)
10	BLOCK, T	ERMINAL	_
	332A604	ŧ	Remote (5-Place) - Prior to Spec C
	332A611	1	Remote (5-Place) - Begin Spec C
11	STRIP, MA	RKER	
	332A679	ŀ	Remote (CL1, CL2, B+, GND, START) - Prior to Spec C
	332A762	1	Remote (GND, B+, REMOTE) - Begin Spec C
12	332P69	t	Receptacle Assy., Pilot Light - Begin Spec C
1 <b>3</b>	332P72	2	Receptacle, Panel Light - Begin Spec C
14	322-4	3	Bulb, Begin Spec C
15	RESISTOR,	FIXED	
	304A32	1	Start-Disconnect to Ignition Relay (15-Ohm, 10-Watt) - Prior to Spec C

REF.	PART NO.	QTY USE	. , , , , , ,
	304A45	ŀ	Off Anti-Dieseling Relay (4-Ohm, 50-Watt)
	304A192	1	Cranking Limiter to Anti- Dieseling Relay (3-Ohm, 10-Watt)
16	307 A655	ŀ	Relay, Emergency Latch - Begin Spec C
17	307B52	1	Relay, Start-Disconnect
18	320A104	1	Limiter, Cranking
19	307 A 388	1	Relay, Time Delay
20	307 B299	I	Relay, Emergency Stop- Prior to Spec C
21	307 B5 I4	1	Relay, Pilot
22	308-91	L	Button, Emergency Stop Res - Prior to Spec C
23	RELAY		·
	307 B 1046	1	Ignition - Pricato Spec C
	307 B597	1	Ignition - Begin Spec C
	307.B1046	ŀ	Anti-Dieseling Solenoid Star Prior to Spec C
24	•	I	Harness Assembly - Engine to Control
25	416A96	1	Clip, Harness (""U" Shaped)
26	332-49	1	Clip, Harness ("O" Shaped)
27	320P165	ŀ	Breaker, Starter Protection
28	301A1685	1	Bracket, Relay Mounting

\* - Order by description, giving Model, Spec & Serial Number (Onan Nameplate).

